



PCCP x DIP TIE-IN DETAIL

NOTES:

1. THE TEST LEAD WIRES SHALL BE STRANDED COPPER AWG WIRE WITH TW, THW, OR THWN
2. RUN ALL WIRES IN 2" PVC SCH. 40 FROM THE CONNECTION POINT UNTIL THEY REACH THE BOTTOM OF TEST STATION ASSEMBLY.
3. FOR PCCP x DIP TIE-IN FITTINGS AND ASSEMBLY, SEE DETAIL C/3.3.
4. AFTER INSTALLATION AND ASSEMBLY, TEST INSTALLING JOINT.

WASHINGTON
SUBURBAN
SANITARY
COMMISSION

APPROVED:

8/12/16
[Signature]
Chief Engineer

STANDARD DETAIL
PCCP x DIP
TIE - IN DETAIL
WITH INSULATING JOINT
AND TEST LEAD WIRES

C
3.4