


SPLICE TAPING NOTES:

1. CUT ANODE LEAD WIRE TO PROPER LENGTH PRIOR TO REMOVING INSULATION.
2. REMOVE INSULATION IN ACCORDANCE WITH SPLICE DETAIL. ON WIRES HAVING A JACKET OVER INSULATION, REMOVE JACKET FOR 1/2 INCH FROM END OF INSULATION.
3. MAINTAIN CLEANLINESS OF STRIPPED WIRE AND ATTACH PRESSURE CONNECTOR, USING EQUIPMENT AS SPECIFIED BY THE CONNECTOR'S MANUFACTURER.
4. COAT CONNECTOR AND BARE WIRE SURFACES, INCLUDING ONE INCH OF ADJACENT INSULATION ON EACH WIRE, WITH SCOTCHKOTE FAST DRYING SEALANT AND ALLOW TO DRY UNTIL TACKY.
5. SPIRAL WRAP THREE HALF-LAPPED LAYERS OF 3/4-INCH WIDE SCOTCH LINERLESS RUBBER SPLICING TAPE 130C OR APPROVED EQUAL.
6. SPIRAL WRAP THREE HALF-LAPPED LAYERS OF 3/4-INCH WIDE SCOTCH VINYL ELECTRICAL TAPE SUPER 88 OR APPROVED EQUAL.

WASHINGTON SUBURBAN SANITARY COMMISSION	APPROVED: <u>8/12/16</u>  Chief Engineer	STANDARD DETAIL SPLICE DETAIL ANODE LEADER TO HEADER CABLE	$\frac{C}{2.3}$
--	---	--	-----------------