



NOTES:

1. BACKFILL ANODES WITH NATIVE SOIL FOR A MINIMUM OF 12 INCHES ON ALL SIDES. DO NOT BACKFILL ANODES WITH SAND OR STONE.
2. DO NOT THERMITE WELD TO PVC PIPE.

WASHINGTON SUBURBAN SANITARY COMMISSION	APPROVED: <u>9/29/16</u>  Chief Engineer	STANDARD DETAIL PVC AWWA C-900 PIPE 4-INCH TO 12-INCH MULTIPLE ANODE PLACEMENT	C 7.13
--	---	---	-----------